




FRAME AND CONSOLE PARTS

For Model: DU980QPDQ3
Designer White

UNDERCOUNTER
DISHWASHER



Illus. No.	Part No.	DESCRIPTION
1	3375299	Console (Includes Item 2)
2	3374811	Insert, Console
3	3375556	Control, Electronic
4	3376359	Fuse, Thermal
5	3374760	Switch, Display
7	304231	Screw, 8-18 x 1/2 (6)
8	3374712	Door Frame (Includes Item 27)
9	3368953	Bolt, Latch

Illus. No.	Part No.	DESCRIPTION
10	3372231	Lever, Latch
11	3369325	Switch, (2)
12	3368955	Pin, Switch (2)
13	3376441	Harness and Protector
14	3376405	Elbow, Harness
15	3400803	Screw (3)
16	3375473	Cover Timer
17	3374501	Motor, Dual
18	3374777	Door, Sound Absorber


Illus. No.	Part No.	DESCRIPTION
19		†Panel, Front (Black/White)
20	3374011	Retainer, Panel
21	3374776	Barrier, Lower Vent
26	3373234	Bearing, Spring (2)
27	3374716	Channel, Retainer (Also Order Item #20)

†Refer To Dishwasher Replacement
Panel Parts List No. 675345

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INNER DOOR PARTS

For Model: DU980QPDQ3
Designer White




Illus. No.	Part No.	DESCRIPTION
1	3371480	Inner Door (Also Order Latch Door Kit 676413)
2	3376066	Latch, Detergent Dispenser
3	3369061	Snap, Detergent Dispenser
4	3369505	Actuator Assembly
5	3369506	Wet Agent, Dispenser
7	3369448	Draw Bar, Electronic
8	3368999	Spring (Draw Bar)
9	3376404	Lid Assembly
10	300106	Spring, Lid
11	3372028	Pin (Lid Hinge)
12	3371710	Screen, Vent
13	3369512	Wet-Agent Cap Assembly
14	3369155	Seal (Wet-Cap)
15	3369051	Screw (9)
16	3371569	Cover, Drip
17	3374772	Damper, Door (2)
18	3374771	Clip, Console Door Retainer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS

For Model: DU980QPDQ3
Designer White



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS

For Model: DU980QPDQ3
Designer White


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3375130	Tub Assembly	20	301958	Clamp	41	3370292	Terminal Box
2	3369078	Tub, Wheel Assembly (8)	21	3376149	Shield, Thermostat	42	300068	Cover Assembly, Terminal Box
3	3368932	Runner (2)	22	3374767	Insulation, Toe & Access	43		†Panel, Front
4	3374849	Leveler (2)	23	98997	Clip (2)		3370868	(Black/White)
5	3370389	Screw, Shoulder (2)	25	304231	Screw, 8–18 x 1/2	44	3369526	Spacer, Corrugated
6	302819	Wheel (2)	26	3374767	Sound Shield	45	3374728	Extension & Clip Assembly
7	343641	Screw, 10–16 x 1/2 (4)	28	3374343	Spring, Door (2)	50	3370555	Bracket, Thermostat
8	3374719	Plate, Latch	29	3375563	Housing, Float Switch	52		Damper, Tub
9	3374720	Screw	30	3369067	Switch, Float		3374773	Side (6)
10	3368994	Gasket	31	3375564	Cover, Switch Housing		3374774	Back
11	3372413	Retainer, Access Panel	32	3376397	Float & Washer Assembly	53	3368987	Support, Heater
12	3369052	Deflector (2)	33	717488	Nut	54	3371578	Screw, 8–32 x 1/2
13	3376843	Heater	34	9742861	Toe Panel	55	3371579	Nut, 8–32
14	717273	Washer, Rubber (2)	35	3369614	Panel, Access	56	3370307	Strain Relief
15	3369073	Nut (2) (Heater Terminal)	36	302868	Screw, 8–18 x 1/2 (4)	57	3369138	Screw, 8–18
16	3374621	Water Valve	37	3369414	Hose, Inlet	58	304666	Retainer, Push (2)
17	304392	Screw, 8–18 x 1/2	39	3374718	Clip, Grounding	59	3374768	Seal, Enclosure
18	3369777	Thermostat, Hi-Limit	40	3374765	Sound Shield			†Refer To Dishwasher Replacement Panel Parts List No. 675345

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PUMP AND MOTOR PARTS

For Model: DU980QPDQ3

Designer White



PUMP AND MOTOR PARTS

For Model: DU980QPDQ3
Designer White


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9740982	Plate, Perforated (Includes Item 5) (Also Order Item 30) See Note A.	13	302711	Seal, Pump Outlet	26	3367197	Support, Pump Mounting (4)
2	3367173	Base, Inlet (Includes Items 1 & 5) (Also Order Item 30) See Note A.	14	3369478	Outlet, Pump (Includes Item 13)	27	3368270	Slinger (See Note A.
3	9741232	Screw, 8–18 x 5/8	15	3369482	Check Valve (Includes Item 6)	28	3378052	Motor & Fan Assembly (Includes Item 27) (Also Order Item 30) See Note A.
4	302710	Seal, Inlet Base	16	717000	Gasket, Pump	29	3369331	Screw (4)
5	302709	Ball, Check	17	3376753	Pump & Motor Assembly (Includes Item 16)	30	675505	Pump Seal Kit (Includes Items 4, 12, 13 & 22)
6	95080	"O" Ring	18	302707	Bushing, Grind	31	303918	Tool, Pump Centering
7	302721	Cover, Valve	19	302718	Chopper Kit (Also Order Item 30) See Note A.	32	356138	Clamp, Hose
8	302738	Valve Stem Kit (Includes Items 12, 13 & 22) See Note A.	20	302705	Sleeve, Drain Impeller	33	3368781	Hose, Drain
9	303883	Separator Assembly (Includes Items 12, 13 & 22) See Note A.	21	9741321	Screw, 8–18 x 5/8	34	3371748	Cap, Drain
10	3400001	Screw	22	302704	Seal, Drain Cover	35	3374757	Shaft, Absorber
11	3376402	Impeller, Wash (Includes Items 12 & 13)	23	302723	Cover, Drain (Also Order Item 30) See Note A.	36	3374756	Weight, Absorber
12	3371152	Screw & Seal 10–32 x 3/4	24	303539	Impeller, Drain Kit (Also Order Item 30) See Note A.	37	3376722	Thermostat
			25	3376157	Base, Pump (Also Order ITEM 30) See Note A.	38	3376723	Seal, O–Ring
						39	3376358	Retainer, Thermostat

NOTE A:
Pump Centering Tool Required
For Pump Re–Assembling—
Order Item 31.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISHRACK PARTS

For Model: DU980QPDQ3
Designer White



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISHRACK PARTS


For Model: DU980QPDQ3
Designer White

Illus. No.	Part No.	DESCRIPTION
1	303722	Clip
2	3368290	Support, Arm (Also Order Items 1 & 8)
3	3368300	Spray Arm, Upper (Also Order Items 1 & 8)
4	3368006	Bumper (2)
5	300848	Tower, Pressure
6	3376961	Wheel & Transport Assembly (4)
7	3375100	Dishrack, Lower (Includes Items 4 & 6)
8	3374702	Support, Lock Spray Arm
9	3369488	Silverware Basket Assembly
10	3369485	Cover, Basket
11	300845	End Cap (Front or Rear)
12	3369071	Track
13	301077	Screw (8)
14	3369980	Housing, Adjuster (2)
15	3369981	Worm (2)
16	3369979	Plate, Mtg. (2) (Adjuster)
17		Arm Assembly (Includes Item 15)
	3369977	Right Side
	3369973	Left Side
18	3375116	Dishrack, Upper
19	717528	Trim, Basket
20	300086	Handle, Basket
21	3375124	Flexrow
22	3369347	Sprayarm, Lower
23	3367910	Cap, Nozzle
24	719576	Bearing, Nozzle
25	3368629	Retainer, Flexrow
26	3371265	Cupshelf, Large (2)
27	3371264	Cupshelf, Small (2)
28	3369913	Clip, Cupshelf (6)
29	3369494	Basket, Utensil (Includes Item 19)
30	3374701	Stop, Track (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Model: DU980QPDQ3
Designer White



Illus. No.	Part No.	DESCRIPTION
1	3369816	Miscellaneous Parts Bag (Includes 2 Screws & 2 Hose Clamps)

LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

LITERATURE PARTS

LIT3369685	Instructions, Installation
LIT3367007	Instructions Installation (Supplement) (Locating Your Water Supply)
LIT3373755	Guide, Use & Care
LIT3376445	Tech Sheet
LIT3374754	Wiring Diagram
LIT3373484	Energy Guide

Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

LIT677967	Do-It Yourself, Manual
-----------	------------------------

ACCESSORY PARTS

4317925	White
4317926	Avocado
4317927	Gold
4317929	Almond
4317930	Toast
4317931	Platinum

4318050	Heavy Duty
---------	------------

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
72032	Black

PAINT, PRESSURIZED SPRAY (13 oz.)

350956	Almond
285006	Superior Black
350942	Primer (White)

PAINT, TOUCH-UP (1 qt.)

978883	Almond (Uncut)
799340	Black (Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

DISHRACK REPAIR

675576	Vinyl Touch-Up (Blue)
675677	Tine Tip Repair Kit (Blue— Enough For Two Complete Dishracks)
676453	Vinyl Touch-Up (White)
675679	Tine Tip Repair Kit (White— Enough For Two Complete Dishracks)
676455	Vinyl Touch-Up (Grey)
676458	Tine Tip Repair Kit (Grey— Enough For Two Complete Dishracks)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST